



# FoodSaver V4980 Bag Cutter Replacement

This guide will show you how to replace the bag cutter if it's too old, dull, or broken.

Written By: Mackenzie Grossgold



## INTRODUCTION

Check to see if the bag cutter needs replacing by following this [troubleshooting guide](#).

## Step 1 — Bag Cutter



- The bag cutter is a small plastic rolling apparatus in the bag cutter arm.
- Lift up the top cover to get to the bag cutter arm.

## Step 2



- Pull the sides of the cutter arm apart, and pull on the bag cutter to remove it from the arm.

To reassemble your device, follow these instructions in reverse order.

